

# Supplementary for MultiEgo

## 1 MultiEgo Dataset Instruction

The dataset contains 5 scenes: talking, statement, concert, sword, and presentation. Each scene provide video, camera intrinsic, camera poses, timestamp, and a sparse point cloud of the first frame scene.

The file construction is as follows:

```
scene
|-cam1
|  |-<scene>-cam1.mp4
|  |-intrinsic.txt
|  |-camera_poses.txt
|  |-samptime.txt
|-cam2
|-cam3
|-cam4
|-cam5
|-sparse
|-camera.bin
|-images.bin
|-points3D.bin
|-points3D.ply
```

where `<scene>-camx.mp4` is the egocentric video of the performer x in the scene. If frame extraction is performed on all videos, it is recommended to reserve 25 GB of storage space.

`intrinsic.txt` is the intrinsic matrix of the camera x, in the format as:

$$\begin{bmatrix} f_x & 0 & c_x \\ 0 & f_y & c_y \\ 0 & 0 & 1 \end{bmatrix} \quad (1)$$

`camera_poses.txt` is the camera poses matrix of the frames in the `<scene>-camx.mp4`. The camera poses are represented as camera-to-world transformations in the world coordinate system. The pose in the format as:

$$\begin{bmatrix} R & t \\ 0 & 1 \end{bmatrix} \quad (2)$$

`samptime.txt` is the capture time of the acquisition system. The data in `samptime.txt` is in the unit of nano-second.

The `sparse` directory contains COLMAP [2] binary files for all images, including intrinsic camera parameters ( `camera.bin` ) and world-to-camera extrinsic transformations ( `images.bin` ).

The `images.bin` file names follow the naming convention `camx_frame_00000.png`. Additionally, we provide sparse 3D point clouds reconstructed from the first frame's images and extensive images, stored in `points3D.bin` and `points3D.ply`.

## 2 Data Loader Example

a data loading pipeline example: Modified from `dataset_readers.py` in 4DGaussian [5].

```
#
# Copyright (C) 2023, Inria
# GRAPHDECO research group,
#   https://team.inria.fr/graphdeco
# All rights reserved.
#
# This software is free for non-commercial, research
#   and evaluation use
# under the terms of the LICENSE.md file.
#
# For inquiries contact george.drettakis@inria.fr
#

import os
...

class CameraInfo(NamedTuple):
    ...

class SceneInfo(NamedTuple):
    ...

def getNerfppNorm(cam_info):
    ...

def getTimeScale(scene):
    timescale=[]
    for num in range(1,6):
        with
            open(f'path/to/{scene}/cam{num}/samptime.txt','r')
            as f:
                txt=f.readlines()
                time=[]
                for i in range(1,len(txt)): # the first line is an
                    annotation
                time.append(float(txt[i]))
                timescale.append(time)
            timescale=np.array(timescale)
            timescale/=np.max(timescale)
        return timescale

def getImageFolder(scene,cid,iid):
    return f'path/to/video/frames/{scene}
        /cam{cid}/frame_{iid:05d}.png'
```

```

# In this example, the frames is in
    {scene}/cam{x}/frame_00000.png

def getCandIid(name): # get cam and image id from
    image_name in colmap .bin file
    split=name.split('_')
    cid=int(split[0][-1])
    iid=int(split[2])
    return cid,iid

def readColmapCameras(scene,cam_extrinsics,
    cam_intrinsics, images_folder):
    # Read the entire timeline before the loop
    timescale_all=getTimeScale(scene)

    cam_infos = []
    for idx, key in enumerate(cam_extrinsics):

        sys.stdout.write('\r')
        sys.stdout.write("Reading camera
            {}/{}".format(idx+1, len(cam_extrinsics)))
        sys.stdout.flush()

    # scale the camera and image
    scale=0.5

    extr = cam_extrinsics[key]
    intr = cam_intrinsics[extr.camera_id]
    height = int(intr.height*scale)
    width = int(intr.width*scale)

    uid = intr.id
    R = np.transpose(qvec2rotmat(extr.qvec))
    T = np.array(extr.tvec)

    if intr.model in ["SIMPLE_PINHOLE", "SIMPLE_RADIAL"]:
        focal_length_x = intr.params[0]*scale
        FovY = focal2fov(focal_length_x, height)
        FovX = focal2fov(focal_length_x, width)
    elif intr.model=="PINHOLE":
        focal_length_x = intr.params[0]*scale
        focal_length_y = intr.params[1]*scale
        FovY = focal2fov(focal_length_y, height)
        FovX = focal2fov(focal_length_x, width)
    elif intr.model == "OPENCV":
        focal_length_x = intr.params[0]*scale
        focal_length_y = intr.params[1]*scale
        FovY = focal2fov(focal_length_y, height)
        FovX = focal2fov(focal_length_x, width)
    else:

```

```

assert False, "Colmap camera model not handled: only
    undistorted datasets (PINHOLE or SIMPLE_PINHOLE
    cameras) supported!"

# get cam num and frame id from image_name
cam_num,img_id=getCandIid(os.path.basename(extr.name).
    split(".")[0])
# get image path
image_path = getImageFolder(scene,cam_num,img_id) #
    os.path.join(images_folder,
    os.path.basename(extr.name))
image_name =
    os.path.basename(image_path).split(".")[0]
image = Image.open(image_path).resize((width,height))
image = PILtoTorch(image,None)
# get timestamp (or automatic allocation)
time= timescale_all[cam_num-1,img_id-1] #
    float(img_id/len(timescale_all[0]))

cam_info = CameraInfo(uid=uid, R=R, T=T, FovY=FovY,
    FovX=FovX,
    image=image,camera_id=cam_num,image_path=image_path,
    image_name=image_name, width=width,
    height=height,time = time, mask=None)
cam_infos.append(cam_info)
sys.stdout.write('\n')
return cam_infos

def fetchPly(path):
    plydata = PlyData.read(path)
    vertices = plydata['vertex']
    positions = np.vstack([vertices['x'], vertices['y'],
        vertices['z']]).T
    colors = np.vstack([vertices['red'],
        vertices['green'], vertices['blue']]).T / 255.0
    # no such normals
    normals = np.vstack([0, 0, 0]).T
    return BasicPointCloud(points=positions,
        colors=colors, normals=normals)

def storePly(path, xyz, rgb):
    ...

# the boundaries of different scene
bound={'talking':[[ -15,-5,-20],[25, 7, 14]],
    'statement':[[ -15,-8,-25],[12, 6, 11]],
    'concert':[[ -12,-15,-17],[15,7,12]],
    'sword':[[ -10,-16,-5],[16, 5, 20]],
    'presentation':[[ -10,-6,-3],[8, 5, 12]]}

# generate random point cloud
def randomPCD(scene):

```

```

num=1e5
xyz_scale=bound[scene]
x=np.random.uniform(xyz_scale[0][0],xyz_scale[1][0],num)
y=np.random.uniform(xyz_scale[0][1],xyz_scale[1][1],num)
z=np.random.uniform(xyz_scale[0][2],xyz_scale[1][2],num)
colors = np.random.randint(0, 256, size=(num, 3))
normals = np.zeros((num, 3))
xyz=np.array([x,y,z]).T

return BasicPointCloud(points=xyz, colors=colors,
    normals=normals)

def readColmapSceneInfo(path, images, eval,
    llffhold=8):
    # get scene
    scene=path.split('/')[1]

    try:
        cameras_extrinsic_file = os.path.join(path,
            "sparse/0", "images.bin")
        cameras_intrinsic_file = os.path.join(path,
            "sparse/0", "cameras.bin")
        cam_extrinsics =
            read_extrinsics_binary(cameras_extrinsic_file)
        cam_intrinsics =
            read_intrinsics_binary(cameras_intrinsic_file)
    except:
        cameras_extrinsic_file = os.path.join(path,
            "sparse/0", "images.txt")
        cameras_intrinsic_file = os.path.join(path,
            "sparse/0", "cameras.txt")
        cam_extrinsics =
            read_extrinsics_text(cameras_extrinsic_file)
        cam_intrinsics =
            read_intrinsics_text(cameras_intrinsic_file)

    reading_dir = "images" if images == None else images
    cam_infos_unsorted = readColmapCameras(scene,
        cam_extrinsics=cam_extrinsics,
        cam_intrinsics=cam_intrinsics,
        images_folder=os.path.join(path,
            reading_dir))
    cam_infos = sorted(cam_infos_unsorted.copy(), key =
        lambda x : x.image_name)

    if eval:
        train_cam_infos = [c for idx, c in
            enumerate(cam_infos) if idx % llffhold != 0]
        test_cam_infos = [c for idx, c in
            enumerate(cam_infos) if idx % llffhold == 0]

```

```

else:
    train_cam_infos = cam_infos
    test_cam_infos = []

nerf_normalization = getNerfppNorm(train_cam_infos)

ply_path =
    f"/path/to/random/pointcloud/{scene}/randomply.ply"

bin_path = os.path.join(path,
    "sparse/0/points3D.bin")
txt_path = os.path.join(path,
    "sparse/0/points3D.txt")
if not os.path.exists(ply_path):
    print("Converting point3d.bin to .ply, will happen
        only the first time you open the scene.")
    try:
        xyz, rgb, _ = read_points3D_binary(bin_path)
    except:
        xyz, rgb, _ = read_points3D_text(txt_path)
    storePly(ply_path, xyz, rgb)

    ## choose one
    # pcd=randomPCD()
    pcd = fetchPly(ply_path)

    scene_info = SceneInfo(point_cloud=pcd,
        train_cameras=train_cam_infos,
        test_cameras=test_cam_infos,
        video_cameras=train_cam_infos,
        maxtime=0,
        nerf_normalization=nerf_normalization,
        ply_path=ply_path)
    return scene_info
def generateCamerasFromTransforms(path,
    template_transformsfile, extension, maxtime):
    ...
    ### no changes followed

```

### 3 Data Processing Details

In the following part, we will explain the details of data annotation process. We assume that after a data acquisition, the  $i$ -th AR glasses acquires a sequence of image frames  $X_i$ , and a sequence of gyroscopic pose frames  $G_i$ .

#### 3.1 Monocular Pose Tracking

As described in Section 3.2 in the paper, each image frame and gyroscopic pose frame has its own timestamp, with image frames captured at 30Hz and gyroscopic pose frames at 50Hz. To align these data streams, we perform Spherical Linear Interpolation (SLERP) on the gyroscopic pose frames to obtain rotation data  $\hat{G}_i$  corresponding

